

FIG. 1




FIG. 2

| DSP | PORT | STATE |
|----------|------|--------|
| DSP 1 | 1 | ENABLE |
| | 2 | BUSY |
| | 3 | FAULT |
| | 4 | ENABLE |
| DSP 2 | 5 | . |
| | 6 | . |
| | 7 | . |
| | 8 | . |
| DSP 3 | 9 | . |
| | 10 | . |
| | 11 | . |
| | 12 | . |
| DSP 4 | 13 | . |
| | 14 | . |
| | 15 | . |
| | 16 | . |

FIG. 3A

| STATE | EVENT |
|---------|---------------------------------|
| SEIZURE | ANNOUNCEMENT MSG #1, 2, 3, 4 |
| | |

FIG. 3B




FIG. 4

VOICE MESSAGE 1 : HELLO,THIS IS SS CORPORATION
VOICE MESSAGE 2 : ENTER USER ID
VOICE MESSAGE 3 : ENTER PASSWORD
VOICE MESSAGE 4 : ENTER CALLED NUMBER

FIG. 5A

552021 " 5353 5353

| MESSAGE NUMBER | MESSAGE |
|-------------------|------------------------------|
| VOICE MESSAGE 1 | HELLO,THIS IS SS CORPORATION |
| VOICE MESSAGE 2 | ENTER USER ID |
| VOICE MESSAGE 3 | ENTER PASSWORD |
| VOICE MESSAGE 4 | ENTER CALLED NUMBER |

FIG. 5B

| MESSAGE NUMBER | MESSAGE |
|-------------------|---|
| VOICE MESSAGE 1 | HELLO,THIS IS SS CORPORATION EOF |
| VOICE MESSAGE 2 | ENTER USER ID EOF |
| VOICE MESSAGE 3 | ENTER PASSWORD EOF |
| VOICE MESSAGE 4 | ENTER CALLED NUMBER EOF |

FIG. 5C




FIG. 6